EVERWIDE No. 36, Dougong 6th Rd., Douliu City, Yunlin County 64069, Taiwan

## **Technical Data Sheet**

**KA 022** 

# Room Temperature Cured Adhesive for Dissimilar Materials

## **Product Description**

KA022 is a two-component acrylic-based adhesive cured at room temperature. No special surface treatment is required. This resin has excellent adhesion to many low surface energy materials after curing, such as polyamide (PA), polypropylene (PP), polyethylene (PE), and thermoplastic polyolefin (TPO). It can replace screws, rivets, plastic welding, and two-step processes, including chemical etchants, primers, or surface treatments in many applications.

#### **Features**

- 1. This product exhibits good handling properties after mixing.
- 2. This product can bond with different plastic materials.
- 3. Excellent adhesion strength of thermoplastic polyolefin elastomers.
- 4. No surface treatment is required.
- 5. This product complies with the 2011/65/EU RoHS regulations.

## **Typical Uncured Properties**

Appearance Color	KA022A Liquid Light yellow	KA022B Liquid Light yellow
Viscosity 25°C, S14 10rpm cps	10,000~20,000	25,000~40,000
Specific Gravity Thixotropic Index	1.06~1.21 >3	1.02~1.12 >3

#### **Typical Curing Properties**

Mix Rate (A: B) by Volume	10:1
Pot Life, 25~33°C, min	5~10
Initial Cure Time, 25~33°C, hr	2~4
Full Cure Time, 25~33°C, hr	24~48

## **Direction of Use**

- 1. When using this product, discard the front end of the A part and B part mixed adhesive, then coat the product (A part and B part mixed adhesive) on the substrate to achieve the best bonding performance.
- 2. It should be applied to a clean surface that is free of dirt, grease, or mold release. In many cases, a simple solvent wipe is sufficient.
- 3. Mix thoroughly by volume 10: 1 before use.
- 4. After mixing, it should be used within the pot life.
- 5. For maximum bonding strength, apply adhesive evenly to both surfaces to be jointed.
- 6. The handling information of this product supplied in a dual syringe cartridge can be obtained by requesting a copy of "Introduction for Adhesive Cartridge Dispenser," F-06122201.

#### Typical Cured Properties\*

Durometer Hardness, Shore D	60~65
Specific Gravity	1.10
Shear Strength, PA vs. PA, kgf/cm <sup>2</sup>	80
Shear Strength, PP vs. PP, kgf/cm <sup>2</sup>	110
Shear Strength, TR90 vs. SUS304, kgf/cm <sup>2</sup>	100
Shear Strength, PA vs. SUS304, kgf/cm <sup>2</sup>	70

<sup>\*</sup> Specimen Cure Condition: Room temperature(25~35 °C)

#### Storage and Shelf Life

This product should be kept without any possibility of light exposure. Replace the lid immediately after use. Please keep the bottle mouth clean and avoid any contact with acid-base a substance after opening. This product has a one-year minimum shelf life when stored in a dark place below 2~13 °C in original, unopened containers.

## **Caution**

Some findings indicate a lack of potential for carcinogenicity with the compositions of this product due to long-term recurrent application to the skin. However, contact with skin is likely to produce mild transient reddening. Removing adhesive from the skin thoroughly with soap and water is important. DO NOT use solvents for cleaning hands. This product has moderate acute toxicity when swallowed. If swallowed, call a physician. Avoid contact with eyes. In case of contact, flush with water for at least 15 minutes and get medical attention immediately. For specific information on this product, consult the Material Safety Data Sheet.

Update: 2024-11-18

The data contained in this bulletin is provided only as a guide for evaluation/consideration. These material characteristics are typical properties that are based on a limited number of samples tested in the laboratory. We cannot assume responsibility for results obtained by others over whose methods we have no control. It is the user's responsibility to determine suitability for the user's purpose of any product or method. We recommend that each prospective user test his proposed application before repetitive use, using this data as a guide.